

Steps for S.A.F.E. model 5250G/55G



model	A (mm/inch)	B (mm/inch)	C (mm/inch)	D (mm/inch)	E (mm/inch)	F (mm/inch)	dynamic load (kg/lbs)	static load (kg/lbs)
5250/90	860 33" 3/5	900 35" 2/5	595 23" 3/5	220 8" 3/5	196 7" 3/4	152 6"	300/660	300/660
5255/90	860 33" 3/5	900 35" 2/5	805 31" 3/4	170 6" 7/10	330 13"	190 7" 1/2	500/1100	650/1400
POSSIBLE CUSTOMIZATION OF DIMENSIONS								

Couple of steps that can be combined with SAFE system 5250/55.
Steps positioning is bound to platform movement. It is possible to install one or two couples of steps.

